



---

# Common Rail Fuel Injector

## 0445120449 CR Fuel Injector Technical File

### Content

|                                                                                            |    |
|--------------------------------------------------------------------------------------------|----|
| 1. 0445120449 CR Fuel Injector Introduction.....                                           | 2  |
| 1.1. 0445120449 CR Fuel Injector Basic Information .....                                   | 2  |
| 1.2. 0445120449 CR Fuel Injector Common Information.....                                   | 2  |
| 1.3. 0445120449 CR Fuel Injector Part Number Common Writing .....                          | 2  |
| 1.4. 0445120449 CR Fuel Injector Parameter.....                                            | 2  |
| 1.5. 0445120449 CR Fuel Injector Customized Service .....                                  | 3  |
| 1.6. 0445120449 CR Fuel Injector Packing List and Package Size .....                       | 3  |
| 1.7. 0445120449 CR Fuel Injector Quality Control.....                                      | 4  |
| 1.8. 0445120449 CR Fuel Injector Testing Standard and Certificate .....                    | 5  |
| 1.9. 0445120449 CR Fuel Injector Warranty Instructions.....                                | 5  |
| 2. 0445120449 CR Fuel Injector Technical Support.....                                      | 6  |
| 2.1. 0445120449 CR Fuel Injector Part Number Location .....                                | 6  |
| 2.2. 0445120449 CR Fuel Injector Application Scenarios.....                                | 7  |
| 2.3. 0445120449 CR Fuel Injector Installation Precautions.....                             | 8  |
| 2.4. Reasons For 0445120449 CR Fuel Injector Not Working Normally .....                    | 8  |
| 2.5. Causes of 0445120449 CR Fuel Injector Being Damaged .....                             | 8  |
| 2.6. 0445120449 CR Fuel Injector Storage Standard .....                                    | 9  |
| 2.7. 0445120449 CR Fuel Injector Technical Support Obtaining Methods.....                  | 10 |
| 3. 0445120449 CR Fuel Injector Purchase and Delivery.....                                  | 10 |
| 3.1. 0445120449 CR Fuel Injector Purchase Payment Term.....                                | 10 |
| 3.2. 0445120449 CR Fuel Injector Main Sales Markets .....                                  | 10 |
| 3.3. 0445120449 CR Fuel Injector Declaration Requirements.....                             | 10 |
| 3.4. 0445120449 CR Fuel Injector Shipping Ways .....                                       | 10 |
| 3.5. 0445120449 CR Fuel Injector Lead time.....                                            | 10 |
| 3.6. 0445120449 CR Fuel Injector Logistics Time for Destination Out of China's Areas ..... | 10 |
| 3.7. 0445120449 CR Fuel Injector Packing .....                                             | 11 |
| 4. Company Information.....                                                                | 12 |
| 4.1. Company Introduction.....                                                             | 12 |
| 4.2. Contact Information .....                                                             | 12 |
| 5. Copyright Statement.....                                                                | 13 |

## 0445120449 CR Fuel Injector Technical File

### 1. 0445120449 CR Fuel Injector Introduction

#### 1.1. 0445120449 CR Fuel Injector Basic Information

| Title | 0445120449 CR Fuel Injector <b>CRIN3-18</b> China Made New |
|-------|------------------------------------------------------------|
| SKU   | G1W20445120449                                             |

#### 1.2. 0445120449 CR Fuel Injector Common Information

##### (1) CR Fuel Injector Exchange Information

| CR Fuel Injector Part Number | Re-manufactured Part Number |
|------------------------------|-----------------------------|
| 0445120449                   | /                           |

##### (2) CR Fuel Injector Application Information

| CR Fuel Injector Part Number | Car Model |   | Car Model |   |
|------------------------------|-----------|---|-----------|---|
| 0445120449                   | /         | / | /         | / |

##### (3) CR Fuel Injector Matching Information

| Vehicle brand | Series | Car Model | Engine Model | Production date | Power KW | Horse power | Emission Standards | Manufacturer | Emissions(L) | Cylinder | Power Source V |
|---------------|--------|-----------|--------------|-----------------|----------|-------------|--------------------|--------------|--------------|----------|----------------|
| /             | /      | /         | /            | /               | /        | /           | /                  | /            | /            | /        | /              |

#### 1.3. 0445120449 CR Fuel Injector Part Number Common Writing

0445120449, 0 445 120 449, 0445 120 449, 0445120 449, 0 445120449, 0 445120 449

#### 1.4. 0445120449 CR Fuel Injector Parameter

CR Fuel Injector Adaptation System: [Common Rail System](#)

CR Fuel Injector Series: [0445120 Series](#)

CR Fuel Injector Parameter Performance: [CRIN3-18](#)

CR Fuel Injector Matching Accessories: [Gasket F 00R J01 453 \(7.73\\*14.36\\*1.49\)](#)

CR Fuel Injector Type: [Electromagnetic CR Fuel Injector](#)

Support System Maximum Pressure: [1,800](#)

Vehicle Configuration Information: [/](#)

CR Fuel Injector Size: [21.5cm\\*4 cm \\*4 cm](#)

CR Fuel Injector Net Weight: [0.55kg](#)

CR Fuel Injector Gross Weight: [0.6kg](#)

CR Fuel Injector Quality: [China Made New](#)

CR Fuel Injector Package Size: [28cm\\*7 cm \\*7 cm](#)

CR Fuel Injector Type: [Common Rail Fuel Injector](#)

CR Fuel Injector MOQ: [4 Pieces](#)



### 1.5. 0445120449 CR Fuel Injector Customized Service

- (1) **CR Fuel Injector Customized Service Coverage:** Meet the customized needs of OEM manufacturers for shell lettering, logo engraving, CR fuel injector internal packaging, CR fuel injector external packaging and labels customized, etc.

| No.   | 1                                                                                 | 2                                                                                 | 3                                                                                  | 4                                                                                   |
|-------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|
| Image |  |  |  |  |
| Name  | CR Fuel Injector Nozzle Engraving                                                 | Injector Housing Engraving and QR Code                                            | CR Fuel Injector Solenoid Valve Engraving                                          | CR Fuel Injector Box And Label                                                      |

### (2) CR Fuel Injector Customized Service Requirements:

- ① The purchase of [customized CR fuel injectors](#) are not less than **10 pieces**.
- ② The purchase of [customized CR fuel injector packages](#) are no less than **1000 pieces**.

When the customized products involve the need of specify logo, the OEM manufacturer is asked to provide trademark authorization and the sample of logo image file.

**⚠ Once the customized CR fuel injector is sold, it cannot be returned or exchanged if there is no quality problems.**

### 1.6. 0445120449 CR Fuel Injector Packing List and Package Size

#### (1) CR Fuel Injector Spare Parts List

| No.         | 1                                                                                   | 2                                                                                                  | 3                                                                                               |
|-------------|-------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------|
| Image       |  |                 |            |
| Name        | CR Fuel Injector                                                                    | O-ring                                                                                             | Gasket <b>F 00R J01 453</b>                                                                     |
| Description | CR fuel injector part number: 0445120449                                            | Ensure to meet the standard of the sealing performance between the CR fuel injector and the engine | Made of brass, used to ensure the tight fit between the CR fuel injector cap end and the engine |
| No.         | 4                                                                                   | 5                                                                                                  | 6                                                                                               |
| Image       |  |                 |            |
| Name        | Nozzle Protective Protective Cover                                                  | CR Fuel Injector Oil Inlet Hole Protective Cover                                                   | CR Fuel Injector Oil Return Hole Protective Cover                                               |
| Description | Protect nozzle holes from being polluted and blocked                                | Protect oil inlet from being polluted and blocked                                                  | Protect the solenoid valve body and terminals from being damaged by external forces             |

| No.         | 7                                                                                 | 8                                                                                 | 9                                                                                   |
|-------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|
| Image       |  |  |  |
| Name        | VCI Anti-rust Bag                                                                 | Bubble Bag                                                                        | CR Fuel Injector Packing Box                                                        |
| Description | Prevent CR fuel injector from rusting                                             | Prevent the CR fuel injector from being damaged by external forces                | Place CR fuel injector and CR fuel injector accessories                             |

⚠ Minors are forbidden to use the CR fuel injector assembly, O-ring, gasket, nozzle protective cover, CR fuel injector house protective cover, solenoid valve protective cover, VCI anti-rust bag, and air bubble bag to avoid personal injury.


⚠ O-ring and gasket are disposable installation accessories, and need to be replaced for re-installation.

⚠ The nozzle protective cover, the CR fuel injector house protective cover, and the solenoid valve protective cover are recyclable accessories that can be reused.

⚠ VCI anti-rust bags and bubble bags are non-degradable materials, please dispose of them properly after using.

⚠ The CR fuel injector and the installation parts should be coated with appropriate sealing oil during installation.

## (2) CR Fuel Injector Box Size



Pic No.1

| No. | Name                 | CR Fuel Injector Package Size (cm) |
|-----|----------------------|------------------------------------|
| 1   | CR Fuel Injector Box | 28*7*7                             |

## 1.7. 0445120449 CR Fuel Injector Quality Control

### (1) CR Fuel Injector Testing

All CR fuel injectors are tested for electrical characteristics, accuracy, high temperature, low temperature, withstand voltage, leakage, durability, and various working conditions.

## (2) CR Fuel Injector Assembling

For quality control during the production and installation process of CR fuel injectors, our company strictly follows the standard product installation data and product installation steps for installation and testing, such as injector stroke test, injector solenoid valve tightening torque test, injector nozzle tightening torque test, etc.

## (3) CR Fuel Injector Inspection

The factory inspection of the CR fuel injector is undergone full inspection, random inspection, and batch inspection three inspections. Different brands of test benches are used to test the same CR fuel injector for more than three times for factory inspection, and the CR fuel injector installation testing environment are progressed in dust-free workshop.

### 1.8. 0445120449 CR Fuel Injector Testing Standard and Certificate

We can provide the factory quality inspection test report of each CR fuel injector to ensure that each CR fuel injector delivered meets the engine performance indicators.

| BOTEN                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |      | 测试报告       |     | 4.05.2019 10:42:09 |    |      |      |     |    |    |    |            |     |     |     |           |   |       |     |     |     |           |   |        |     |     |     |           |   |      |      |            |     |            |   |     |      |            |     |            |   |     |      |            |     |            |   |     |     |           |     |           |   |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------|------------|-----|--------------------|----|------|------|-----|----|----|----|------------|-----|-----|-----|-----------|---|-------|-----|-----|-----|-----------|---|--------|-----|-----|-----|-----------|---|------|------|------------|-----|------------|---|-----|------|------------|-----|------------|---|-----|------|------------|-----|------------|---|-----|-----|-----------|-----|-----------|---|
| 企业名称: _____<br>电话: _____ 地址: _____<br>传真: _____ 检测人: _____<br>客户地址: _____<br>电话: _____ 检测单位: _____<br>传真: _____ 客户姓名: _____<br>检测描述: _____<br>检测名称: 检测器<br>型号/零件号: _____<br>检测方向: _____                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |      |            |     |                    |    |      |      |     |    |    |    |            |     |     |     |           |   |       |     |     |     |           |   |        |     |     |     |           |   |      |      |            |     |            |   |     |      |            |     |            |   |     |      |            |     |            |   |     |     |           |     |           |   |
| <b>检测结果</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |      |            |     |                    |    |      |      |     |    |    |    |            |     |     |     |           |   |       |     |     |     |           |   |        |     |     |     |           |   |      |      |            |     |            |   |     |      |            |     |            |   |     |      |            |     |            |   |     |     |           |     |           |   |
| 检测器型号: CDS002-6511<br><table border="1"> <thead> <tr> <th>检测项目</th> <th>检测结果</th> <th>标准值</th> <th>单位</th> <th>备注</th> <th>合格</th> </tr> </thead> <tbody> <tr> <td>LEAK TEST:</td> <td>0.0</td> <td>0.5</td> <td>MPa</td> <td>0.0 ± 0.1</td> <td>✓</td> </tr> <tr> <td>Back:</td> <td>0.0</td> <td>0.5</td> <td>MPa</td> <td>0.0 ± 0.1</td> <td>✓</td> </tr> <tr> <td>WIPER:</td> <td>0.0</td> <td>0.5</td> <td>MPa</td> <td>0.0 ± 0.1</td> <td>✓</td> </tr> <tr> <td>Max:</td> <td>20.5</td> <td>20.5 ± 0.5</td> <td>MPa</td> <td>20.5 ± 0.5</td> <td>✓</td> </tr> <tr> <td>TL:</td> <td>20.5</td> <td>20.5 ± 0.5</td> <td>MPa</td> <td>20.5 ± 0.5</td> <td>✓</td> </tr> <tr> <td>IL:</td> <td>14.1</td> <td>14.1 ± 0.5</td> <td>MPa</td> <td>14.1 ± 0.5</td> <td>✓</td> </tr> <tr> <td>VE:</td> <td>0.7</td> <td>0.7 ± 0.1</td> <td>MPa</td> <td>0.7 ± 0.1</td> <td>✓</td> </tr> </tbody> </table> |      |            |     |                    |    | 检测项目 | 检测结果 | 标准值 | 单位 | 备注 | 合格 | LEAK TEST: | 0.0 | 0.5 | MPa | 0.0 ± 0.1 | ✓ | Back: | 0.0 | 0.5 | MPa | 0.0 ± 0.1 | ✓ | WIPER: | 0.0 | 0.5 | MPa | 0.0 ± 0.1 | ✓ | Max: | 20.5 | 20.5 ± 0.5 | MPa | 20.5 ± 0.5 | ✓ | TL: | 20.5 | 20.5 ± 0.5 | MPa | 20.5 ± 0.5 | ✓ | IL: | 14.1 | 14.1 ± 0.5 | MPa | 14.1 ± 0.5 | ✓ | VE: | 0.7 | 0.7 ± 0.1 | MPa | 0.7 ± 0.1 | ✓ |
| 检测项目                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | 检测结果 | 标准值        | 单位  | 备注                 | 合格 |      |      |     |    |    |    |            |     |     |     |           |   |       |     |     |     |           |   |        |     |     |     |           |   |      |      |            |     |            |   |     |      |            |     |            |   |     |      |            |     |            |   |     |     |           |     |           |   |
| LEAK TEST:                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | 0.0  | 0.5        | MPa | 0.0 ± 0.1          | ✓  |      |      |     |    |    |    |            |     |     |     |           |   |       |     |     |     |           |   |        |     |     |     |           |   |      |      |            |     |            |   |     |      |            |     |            |   |     |      |            |     |            |   |     |     |           |     |           |   |
| Back:                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | 0.0  | 0.5        | MPa | 0.0 ± 0.1          | ✓  |      |      |     |    |    |    |            |     |     |     |           |   |       |     |     |     |           |   |        |     |     |     |           |   |      |      |            |     |            |   |     |      |            |     |            |   |     |      |            |     |            |   |     |     |           |     |           |   |
| WIPER:                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | 0.0  | 0.5        | MPa | 0.0 ± 0.1          | ✓  |      |      |     |    |    |    |            |     |     |     |           |   |       |     |     |     |           |   |        |     |     |     |           |   |      |      |            |     |            |   |     |      |            |     |            |   |     |      |            |     |            |   |     |     |           |     |           |   |
| Max:                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | 20.5 | 20.5 ± 0.5 | MPa | 20.5 ± 0.5         | ✓  |      |      |     |    |    |    |            |     |     |     |           |   |       |     |     |     |           |   |        |     |     |     |           |   |      |      |            |     |            |   |     |      |            |     |            |   |     |      |            |     |            |   |     |     |           |     |           |   |
| TL:                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | 20.5 | 20.5 ± 0.5 | MPa | 20.5 ± 0.5         | ✓  |      |      |     |    |    |    |            |     |     |     |           |   |       |     |     |     |           |   |        |     |     |     |           |   |      |      |            |     |            |   |     |      |            |     |            |   |     |      |            |     |            |   |     |     |           |     |           |   |
| IL:                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | 14.1 | 14.1 ± 0.5 | MPa | 14.1 ± 0.5         | ✓  |      |      |     |    |    |    |            |     |     |     |           |   |       |     |     |     |           |   |        |     |     |     |           |   |      |      |            |     |            |   |     |      |            |     |            |   |     |      |            |     |            |   |     |     |           |     |           |   |
| VE:                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | 0.7  | 0.7 ± 0.1  | MPa | 0.7 ± 0.1          | ✓  |      |      |     |    |    |    |            |     |     |     |           |   |       |     |     |     |           |   |        |     |     |     |           |   |      |      |            |     |            |   |     |      |            |     |            |   |     |      |            |     |            |   |     |     |           |     |           |   |
| 检测日期: 4.05.2019 10:42:09<br>检测地点: 检测器<br>检测人: 检测器<br>检测单位: 检测器<br>检测方向: 检测器                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |      |            |     |                    |    |      |      |     |    |    |    |            |     |     |     |           |   |       |     |     |     |           |   |        |     |     |     |           |   |      |      |            |     |            |   |     |      |            |     |            |   |     |      |            |     |            |   |     |     |           |     |           |   |

Pic No.2

### 1.9. 0445120449 CR Fuel Injector Warranty Instructions

#### (1) Product Warranty Conditions and Instructions

It is necessary to provide pictures, videos, or test reports detected by the CR fuel injector inspection equipment as evidence to feed back to the salesman when the CR fuel injector is abnormal during using.

Abnormal conditions are properly explained such as: 1. Smoke, 2. Engine shake, 3. Difficulty starting the engine, 4. Engine noise, 5. Oil leakage etc.

## **(2) CR Fuel Injector Warranty Coverage**

Within 15 days after customer receives the 0445120449 CR fuel injector, if there is a performance failure and the product has no appearance damage, customer can choose to replace it or repair it;

If the 0445120449 CR fuel injector has performance problems during the warranty period (6-12 months), and it is confirmed that it is product's problems after testing, you can contact our salesmen to replace the same model or a reworked product with the same performance for free;

If the CR fuel injector house has obvious scratches, it can only be repaired and it will be returned as it is if the product is confirmed to be fault-free.

**⚠ Tips:** For products not covered by warranty, our company can provide paid maintenance services. For products after paid repaired, the same performance problem will have a free warranty period within 3 months from the date of repairing.

## **(3) CR Fuel Injector Out of Warranty Coverage**

- ① The warranty period has expired.
- ② CR fuel injector failure caused by high temperature, high pressure, humidity, rain and snow, saline-alkali land, earthquake, and used in abnormal environment.
- ③ Customer disassembles or repairs the CR fuel injector personally resulting in damage to the CR fuel injector.
- ④ CR fuel injector damage caused by man-made reasons (throwing, strong magnetic field magnetization, set fire).
- ⑤ CR fuel injector failure or CR fuel injector damage caused by non-CR fuel injector design, technology, manufacturing, quality and other issues.
- ⑥ CR fuel injector failure due to system pressure exceeding system approved pressure.
- ⑦ CR fuel injector failure caused by system voltage exceeding approved voltage.
- ⑧ CR fuel injector failure caused by impurities (water, lead, aluminum powder, iron powder, sulfide) in the system fuel exceeding the standard requirements.
- ⑨ CR fuel injector failure caused by not installing according to the tightening torque specified in the vehicle engine maintenance manual (the tightening torque is too large or too small).
- ⑩ CR fuel injector failure caused by not following the installation angle specified in the vehicle engine maintenance manual.
- 11 CR fuel injector failure caused by not following the cleaning requirements specified in the vehicle engine maintenance manual.
- 12 CR fuel injector failure caused by failure to replace consumable parts as specified in the vehicle engine maintenance manual.
- 13 CR fuel injector failure caused by not complying with the intake system fit clearance and exhaust system fit clearance requirements specified in the vehicle engine maintenance manual.
- 14 Failure to replace the consumable parts and the fitting clearance of the oil inlet system pipeline and the CR fuel injector connection in accordance with the fuel intake system specified in the vehicle engine maintenance manual.

## **2. 0445120449 CR Fuel Injector Technical Support**

### **2.1. 0445120449 CR Fuel Injector Part Number Location**



E.g.: See the CR fuel injector part number as follows:




Pic No.3

| No. | Name                                    |
|-----|-----------------------------------------|
| A   | Brand, logo, part number, series number |
| B   | Nozzle part number                      |

## 2.2. 0445120449 CR Fuel Injector Application Scenarios

Common rail system is an oil supply method refers to the Fuel oil from the fuel tank sucked out by the gear pump through the oil-water separator and the gear pump to Fuel fine filter, high-pressure pump, common rail pipe, and CR fuel injector, all together with the closed-loop fuel supply system composed of sensors and ECU that completely separates the generation of injector pressure and the injector process from each other.



Pic No. 4

| No. | Name               | No. | Name                        | No. | Name                        | No. | Name                      |
|-----|--------------------|-----|-----------------------------|-----|-----------------------------|-----|---------------------------|
| 1   | Tank               | 5   | Common Rail Pressure Sensor | 9   | Engine Crankshaft Sensor    | A   | High Pressure Oil Circuit |
| 2   | Fuel Filter        | 6   | Common Rail Pipe            | 10  | Camshaft Sensor             | B   | Low Pressure Oil Circuit  |
| 3   | High-Pressure Pump | 7   | CR Fuel Injector            | 11  | ECU Electronic Control Unit | /   | /                         |
| 4   | Fuel Gear          | 8   | Accelerator Pedal           | /   | /                           | /   | /                         |



|  |      |  |  |  |  |  |  |
|--|------|--|--|--|--|--|--|
|  | Pump |  |  |  |  |  |  |
|--|------|--|--|--|--|--|--|

### 2.3. 0445120449 CR Fuel Injector Installation Precautions

- (1) The replacement of the CR fuel injector must strictly follow the electrical system, the approved pressure of the low-pressure fuel intake system, the approved pressure of the high-pressure fuel circuit system, and fuel system replacement consumables requirements (including the low-pressure fuel circuit system filter and the high-pressure fuel circuit) specified in the vehicle engine maintenance manual.
- (2) Replacement of wearing parts of the fuel system, cleaning requirements for the connection between the fuel system and the CR fuel injector, the fitting clearance of the CR fuel injector connection, the installation angle and tightening torque of the CR fuel injector, the fitting clearance of the intake system, and the fitting clearance of the exhaust system to ensure the service life of the engine and the normal operation of the CR fuel injector.
- (3) When installing the CR fuel injector on the engine, it is necessary to clean the engine block, cylinder head and other parts connected to the CR fuel injector, and ensure that there is no dust, carbon deposits, water, rust spots, etc.
- (4) Before installing, check whether the CR fuel injector nozzle gasket has been replaced and installed on the CR fuel injector.
- (5) When installing the CR fuel injector, apply lubricant between the CR fuel injector, fuel nozzle sealing gasket and O-ring.
- (6) Failure to replace the gasket with a new one may result in: deformation of the tight cap of nozzle, deformation of nozzle, deformation of nozzle orifice, oil leakage and air leakage, which will cause serious damage to the CR fuel injector and nozzle to break and cause damage to the engine.
- (7) When installing the CR fuel injector on the engine, please carefully check the components related to the installation of the CR fuel injector, such as the CR fuel injector pressure plate, screw, CR fuel injector rod and other accessories are not deformed, and install it in strict accordance with the operation steps of the engine maintenance manual.
- (8) It is forbidden to operate the bare CR fuel injector for a long time in an environment with serious dust pollution and corrosion to iron products.
- (9) It is forbidden to operate the bare CR fuel injector for a long time in a strong magnetic field environment.

### 2.4. Reasons For 0445120449 CR Fuel Injector Not Working Normally

- (1) There is air in the oil circuit of the engine fuel system.
- (2) Vehicle oil pump oil supply system is not normal.
- (3) Engine common rail system oil leakage or pressure limiting valve is damaged.
- (4) There is a short circuit, cutting out and poor contact in the wiring harness connected to the CR fuel injector of the vehicle.
- (5) The long-term placement of the CR fuel injector causes the anti-rust oil to solidify, and the internal components are stuck or the oil holes are blocked.

**⚠ Before installing, carefully check whether other components in the common rail system except the CR Fuel injector are damaged so as to prevent the CR fuel injector from not working properly after being replaced.**

### 2.5. Causes of 0445120449 CR Fuel Injector Being Damaged

- (1) Failure to operate correctly according to the engine maintenance manual during disassembly and assembly resulted in damage to the CR fuel injector.
- (2) The fuel used for the vehicle does not meet the standard, causing damage to the CR fuel injector, such

as: the water content in the fuel oil exceeds the standard, iron powder, aluminum powder, sulfide impurities exceed the standard, etc.

- (3) The engine is not regularly maintained according to the engine maintenance manual (please refer to the vehicle maintenance manual for the maintenance mileage). For example, failure to replace the lubricating oil of the engine system for a long time will cause abnormal wear of the engine, excessive exhaust gas volume or a large amount of carbon deposits inside the engine. The filter is not replaced during maintenance or the replaced filter cannot reach the original filter standard. All above reasons can cause damage to the CR fuel injector.
- (4) The abrasion of the oil pump produces iron powder and aluminum powder enter the CR fuel injector and cause damage to the CR fuel injector.
- (5) The deformation and abrasion of fuel tank result in iron powder or aluminum powder entering the CR fuel injector and causing damage to the CR fuel injector.
- (6) The CR fuel injector is damaged due to replacement or adjustment of the relevant parts of the CR fuel injector. For example, the valve clearance does not meet the standard after the engine is repaired, the replacement or modification of the wiring harness connected to the CR fuel injector fails to meet the original standard.
- (7) The engine is overheated and overloaded for a long time working results in damage to the CR fuel injector.
- (8) The CR fuel injector will be damaged naturally at the end of its working life.
- (9) The CR fuel injector is magnetized (CR fuel injector parts' magnetic exceeded) causing the CR fuel injector to not work properly.

**⚠ Before replacing the CR fuel injector, please check the engine parts carefully according to the engine maintenance manual to avoid the CR fuel injector being damaged again after replacement.**

## **2.6. 0445120449 CR Fuel Injector Storage Standard**

### **(1) Choose a Suitable Storage Place**

The warehouse and cargo yard where the CR fuel injector is stored should be kept clean and dry, and away from the factory buildings that generate harmful gases and dust; do not mix with acids, alkali, salts and other substances; the storage place should have a good drainage system; the cargo yard should be flattened with gravel or furnace ash etc. to enhance the water permeability of the surface layer to keep the reservoir area dry.

### **(2) Strict Requirements of Warehousing**

Strict inspections should be carried out when the CR fuel injectors are put into storage, the surface cleaning work should be done well to remove water traces, oil stains, ash and other dirt, remove the rust and do anti-rust treatment in time. Packaged CR fuel injectors must be protected from damage.

### **(3) Keep The Warehouse Dry And Preventing Moisture**

The relative humidity is usually below 70% for the CR fuel injectors placed in the room, and the corrosion of the CR fuel injectors is significantly reduced.

CR fuel injectors must be stored in the warehouse, and they are forbidden to store in the same warehouse with commodities with high water content.

### **(4) Stack Properly**

After the CR fuel injector is exposed to rain, the corrosion rate will increase significantly. The purpose of sealing is to isolate the CR fuel injector from rainwater and humid air, so the warehouse window should be

checked in time to avoid rainwater entering the warehouse.

If the CR fuel injector package is damaged, it should be repaired or replaced; when the package is damp, the packaging material should be dried; if the original anti-corrosion and oil applied at the factory is found to be damaged or dried up, it should be cleaned and re-applied oil in time.

⚠ It is forbidden to leave the CR fuel injector exposed in the air for a long time.

⚠ It is forbidden to store acids, alkalis, salts and other substances together with the CR fuel injector.

⚠ The unpacked CR fuel injector must be rust-proof during secondary storage.

## 2.7. 0445120449 CR Fuel Injector Technical Support Obtaining Methods

- (1) CR Fuel Injector Technical File: <https://www.crfuelinjectors.com/download/>
- (2) CR Fuel Injector Videos: <https://www.crfuelinjectors.com/videos/>
- (3) CR Fuel Injector Encyclopedia: <https://www.crfuelinjectors.com/category/news/encyclopedia/>

## 3. 0445120449 CR Fuel Injector Purchase and Delivery

### 3.1. 0445120449 CR Fuel Injector Purchase Payment Term

**Payment Terms:** T/T, PayPal, Alipay, WeChat

⚠ Please contact our salesmen for specific payment information.

### 3.2. 0445120449 CR Fuel Injector Main Sales Markets

CR Fuel Injector Main Sales Markets: Asia, Europe, North America, South America, Africa etc.

### 3.3. 0445120449 CR Fuel Injector Declaration Requirements

We can assist customers to provide the following documents for import customs clearance: contract, invoice, packing list, bill of lading, insurance policy, certificate of origin, etc.

### 3.4. 0445120449 CR Fuel Injector Shipping Ways

**Destination in China Areas:** SF Express, Debon Express, the corresponding logistics company can be provided according to customer requirements in special cases.

**Destinations Out of China's Areas:** DHL, UPS, FedEx, TNT air, ocean or other shipping methods required by customers.

### 3.5. 0445120449 CR Fuel Injector Lead time

**Lead Time:** Send out within 3 – 7 working days after receiving payment (Except for special products and special cases) .

### 3.6. 0445120449 CR Fuel Injector Logistics Time for Destination Out of China's Areas

**DHL Logistics Time :**

| Country or Region of Departure | Hong Kong, China | Other Countries or Regions of Asia | Australia and New Zealand | Europe | America   | Other Countries |
|--------------------------------|------------------|------------------------------------|---------------------------|--------|-----------|-----------------|
| China's Mainland               | 7 Days           | 7 Days                             | 8 Days                    | 8 Days | 8-12 Days | 7-10 Days       |

**UPS Logistics Time: Country or Region of Departure: China's Mainland**

| Country of Destination | Estimated Arrival Time | Country of Destination | Estimated Arrival Time | Country of Destination | Estimated Arrival Time |
|------------------------|------------------------|------------------------|------------------------|------------------------|------------------------|
|------------------------|------------------------|------------------------|------------------------|------------------------|------------------------|

|             |           |             |           |                      |           |
|-------------|-----------|-------------|-----------|----------------------|-----------|
| Japan       | 3 Days    | UK          | 5-7Days   | Egypt                | 5-7 Days  |
| Turkey      | 5-7 Days  | Singapore   | 3 Days    | Switzerland          | 5-7 Days  |
| Bahrain     | 5-7 Days  | Latvia      | 7-10 Days | New Zealand          | 7-10 Days |
| Sri Lanka   | 5-7 Days  | Thailand    | 3 Days    | Austria              | 5-7 Days  |
| Romania     | 5-7 Days  | Vietnam     | 3-5 Days  | Estonia              | 5-7 Days  |
| Malaysia    | 3-5 Days  | Israel      | 5-7 Days  | Mexico               | 7-10 Days |
| France      | 5-7 Days  | America     | 5-7 Days  | United Arab Emirates | 5-7 Days  |
| Italy       | 5-7 Days  | Netherlands | 5-7 Days  | Bengal               | 7-10 Days |
| Lebanon     | 5-7 Days  | Philippine  | 3-5 Days  | Greece               | 7-10 Days |
| South Korea | 3 Days    | Spain       | 5-7 Days  | Myanmar              | 5-7 Days  |
| Canada      | 5-7 Days  | Germany     | 5-7 Days  | Saudi Arabia         | 7-10 Days |
| Portugal    | 5-7 Days  | Australia   | 5-7 Days  | South Africa         | 7-10 Days |
| Denmark     | 5-7 Days  | Belgium     | 5-7 Days  | Ukraine              | 7-10 Days |
| India       | 7-10 Days | Qatar       | 7-10 Days | Poland               | 5-7 Days  |
| Indonesia   | 3-5 Days  | Morocco     | 7-10 Days | Pakistan             | 7-10 Days |
| Kuwait      | 7-10 Days | /           | /         | /                    | /         |

⚠ The logistics time is for reference only and is subject to the actual arrival.

### 3.7. 0445120449 CR Fuel Injector Packing

**Domestic Express Packaging:** Usually wrapped in waterproof scotch tape.

**International Express Packaging:** Wrapped with waterproof yellow tape after wrapping the black protective film.

**Pallet Shipping:** Use fumigation free and recycling trays that meet export requirements, and use white wrapping protective film to wrap and bind with cable ties for the outside, also, the products can be packaged according to customers' requirements.

⚠ The packing tray is made of plastic and can be recycled.

⚠ Transparent tape, yellow tape, black wrapping protective film, white wrapping protective film are non-degradable materials, please dispose of them properly.

⚠ Minors are prohibited from using transparent tape, yellow tape, black wrapping protective film, and white wrapping protective film to avoid personal injury.

| No.   | 1                                                                                   | 2                                                                                    | 3                                                                                     |
|-------|-------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
| Image |  |  |  |
| Name  | Domestic Express Packaging                                                          | International Express Packaging                                                      | Pallet Shipping                                                                       |



|                    |                             |                                                               |                                                                                                                   |
|--------------------|-----------------------------|---------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------|
| <b>Description</b> | Wrapped by transparent tape | Wrapped with yellow tape after wrapping black protective film | Use pallet that meet export requirements, and use white wrapping protective film to wrap and bind with cable ties |
|--------------------|-----------------------------|---------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------|

#### 4. Company Information



Pic No. 5

##### 4.1. Company Introduction

 **Mob Phone/WeChat:** +86-13410541523

 **HK Telephone:** +852-67653519

 **Telephone:** +86-755-23215133

 **Shenzhen Office:** 11-12, Floor 14, Building 13, Qinchengda Building, Exit A, Honglang North Subway Station, Bao'an District, Shenzhen, China's Mainland

 **Shenzhen Office:** Exit C, Qiao Touxu Metro Station, NO. 66 Chongqing Road, Fuhai Avenue, Bao'an District, Shenzhen, China Mainland

 **Hong Kong Office:** Jianfa Street Industrial Zone, Tuen Mun, New Territories, Hong Kong, China

 **After-sales Service Address:** Please contact our salesmen to obtain and provide the corresponding product maintenance reasons (Reference: [1.9. 0445120449 CR Fuel Injector Warranty Instructions](#))

##### 4.2. Contact Information

| Name | WeChat/ WhatsApp |
|------|------------------|
| Ruby | +86-13410541523  |

## 5. Copyright Statement

All content on this website, including but not limited to text, graphics, logos, icons, images, video clips, is the property of Shenzhen Shumatt Technology Co., Ltd. and its content suppliers and protected by relevant international conventions and the laws of the People's Republic of China.

The content on “[0445120449 CR Fuel Injector Technical File](#)” may be used as a resource while accessing this website. Any other use, including the reproduction, modification, distribution, transmission, republication, display, or performance, of the content on this site is strictly prohibited without the express written permission of Shenzhen Shumatt Technology Co., Ltd. Unauthorized use of any copyrighted material on the website may constitute a violation of the copyright laws.

We respects the intellectual property of others, and we ask our users to do the same. We may, in appropriate circumstances and at its discretion, pursue legal liability, disable or terminate the accounts of users who may be repeat infringers.